



NanoReef

Trouble Shooting

If you are in any doubt about the electrical installation or safety of this product you must consult a qualified electrician.

BUBBLES ARE COMING OUT THE OUTLET INTO THE AQUARIUM

1. The water level in the filter is too low. Check specific gravity after topping up to the correct level.
2. The flow to the pump is restricted. Check the sponge and clean if necessary.

WATER FLOW INTO THE AQUARIUM HAS DROPPED

1. Pump needs to be cleaned. Refer to maintenance instruction provided with pump .
2. Outlet is blocked. Remove and clean the duckbill outlet.