



Substrate Heating Cables

25W 100W 150W

Trouble Shooting

HEATER DOES NOT WORK

1. Ensure the plug is inserted correctly and the switch is in the on position.
2. Double check the thermometer. Use a second one.
3. Return the unit to the place of purchase for further inspection.