



# ThermoSafe Heaters

## 25W 50W 100W

## 150W 200W 300W

### Trouble Shooting

#### HEATER DOES NOT WORK

1. Ensure the plug is inserted correctly and the switch is in the on position.

#### THE LED IS WORKING, BUT THE HEATER IS NOT HEATING THE AQUARIUM

1. Check that the Dial is set on the desired temperature.
2. Double check the thermometer. Use a second one.
3. Ensure the thermometer is not near the heater. Relocate the thermometer to the opposite end of the aquarium.
4. Return the unit to the place of purchase for further inspection.

#### THERE IS WATER INSIDE THE HEATER

1. Turn the power off at the main power supply, unplug the unit and remove it from the aquarium. If the unit is still under guarantee return it to the place of purchase for further inspection, Other wise cut the cord and dispose of sensibly